

Index

AirCardTM Pro User Manual

- Getting Started
- Add Your Item Locator
- Basic Features
- When Your Item Is Lost
- Resetting Item Locator
- Wireless Charging
- Extras
- 08 The Fine Print
- Safety and Notice
- Specification




EU Declaration of conformity / Video tutorial:

https://rsqr.ch/qr/ACP02S

Getting Started

01



01.1 Power On:

• Turn on the device: Place your card on a hard surface, press and hold the button very hard until it beeps and turns on (approximately 5 seconds). Please note that the button is designed to be firm to prevent accidental pressing in your wallet. (To confirm whether the device has been turned on, double-click the device button; it will produce a sound, indicating that the device is on).

01.2 Power Off:

• Turn off the device: press and hold the button 5 times consecutively until it makes a sound, and the LED blinks 5 times.

O2 Add Your Item Locator

02.1 Download the App

- Go to Google Play and search for 'Find My Device'
- Install the app or click to 'Update'.
- Hit 'Open' or click on the Find My Device app icon on your phone home page.
- Log in to the Find My Device page with your Google account.
- You might be asked to allow some permissions. Review the terms and continue.

02.2 Connect Your Item Locator

- Make sure your phone's Bluetooth is ON and you are connected to the Internet.
- Bring your AirCard™ Pro close to your phone.
- Once your Item Locator is located, tap "Agree".
- There is no button on the Find My Device app to trigger the bottom sheet. It should automatically appear when you activate your unit close to the phone.
- Tap on "connect" button on the Find My Device app to pair your Item Locator.

Basic Features

03

AirCard Pro works exclusively with Google's Find My Device Network through the Find Device app on your Android device. The Find Device app can help you locate a missing item by making AirCard Pro play a sound when nearby and by displaying its last known location on a map.

Find a lost item by marking AirCard Pro as lost in the Find Device app and get a notification when Google's Find My Device locates it.

04 When Your Item is Lost

04.1 "Secure Device":

- Launch the Find My Device app and tap your lost device.
- From the options in the bottom menu, tap on Secure device.
- Add content info if needed so that if someone finds vour device, it will be easier for them to contact you.
- Check the Mark as lost box if you want to be notified when the Find My Network detects your device.
- tap on the Secure button.

04.2 "Mark as Lost":

- Launch the Find My Device app and tap your lost device.
- From the options at the bottom, tap on Mark as lost.
- Add contact info and a phone number as needed. This is the contact detail that will show up on the lost device when found by someone.
- tap Mark as lost.

Resetting Item Locator 05

05.1 Remove The Item From Find My Device App:

- Open Find My Device app and select the "Items" tab.
- Tap on your Item Locator from the list.
- Please ensure "Lost Mode" is disabled.
- Tap the setting Icon.
- Tap "Remove from Find My Device"

05.2 Factory Reset Your Item Locator:

- When the device is turned on, rapidly click 4 times the device button (the device will sound, and the LED will blink three times), and then, press and hold the device button. After 2 seconds, you will hear a sound, and the LED will blink again. Then, release the button.
- The Item Locator is now reset and ready to be paired to a new device.

06 Wireless Charging

06.1 Set up the charger:

- Place your wireless charger on a flat surface.
- Plug the charging cable into the wireleess charger and into the power adapter
- Plug the Adapter into a power outlet

06.2 Charge AirCard Pro:

- Place your AirCard Pro centered on the wireless charger.
- the LED on AirCard Pro switches on when the card starts charging.
- When AirCard Pro is fully charged the LED will switch off

Extras 07

07.1 QR Code

- You can use the QR code on the front of the card to share your contact info, website links, use payment apps and much more.
- Scan the QR code with your phone to instantly share your info

08 The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or Tv interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device. The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

09

Safety and Notice

Safety

The recommended temperature range for devices and accessories is 0°C to 50°C (32°F-122°F). Unless specifically indicated that it is safe to do so in the Unless specifically indicated that it is safe to do so in the user guide or instruction manual, do not use this device in and environment that exceeds the recommended low or high temperature. Unless specifically indicated that it is safe to do so in the user guide or instruction manual, avoid exposing your device to direct sunshine or excessively wet environments.



THERE IS A RISK OF EXPLOSION IF AN INCORRECT BATTERY TYPE IS USED. DISPOSE OF USED BATTERIES ACCORDING TO THEIR INSTRUCTIONS.

Warning

- · Replacing a battery with an incorrect type may bypass safeguards and create
- Disposal of a battery in a fire or other source of significant heat, or by crushing, or cutting, may result in and explosion as well as leakage of flammable liquids and gases:
- Leaving a battery in an extremely hot environment may result in an explosion as well as leakage of flammable liquids and gases:
- A battery subjected to extremely low air pressure may result in an explosion as well as leakage of flammable liquids and gases.

Notice

CE This product complies with the radio interference requirements of the European Community.

Declaration of Conformity

Hereby, Rolling Square declares that the radio equipment type AirCard Bluetooth item finder is in compliance with Directive 2014/53/FU, at the following internet address: https://rsgr.ch/gr/ACP02S



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. Your product is desianed and manufactured with high quality materials and components, which can be recycled and reused. This sympol means the product must not be discarded as housenold waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For

more information on disposal and recycling of this product, contact your local municipality disposal service or the shop where you bought this product.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference. and (2) this device must accept any interference received. including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that pro entich he receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

FCC Radio Frequency Exposure Statement. The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables

to maintain compliance with FCC regulations. RF exposure information:

The device has been evaluated to meet general RF exposure requirements. The device came used in portable exposure condition without restriction. The min separation distance is

Frequency bands and power as below:

Bluetooth Operation Frequency: 2402-2480MHz; Bluetooth Max.

Power: 2.85 dBm

The following importer is the responsible party:

Rolling Square SA | Corso San Gottardo 99. Chiasso CH6830. Switzerland.

10

Specifications

Range: up to 60 m (200 ft) [60 m] - line of sight

Temperature range: -15 °C to +50 °C (5 °F [-15°C] to 122 °F [50°C])

Modulation method: GFSK Antenna power: < 1 mW

Operating frequency band: 2402-2480 MHz





Points de collecte sur www.quefairedemesdechets.fr Privilégiez la réparation ou le don de votre appareil!

